



Step Down Chopper

Step Down Chopper:

A Chopper is simply an 'on-off' switch that either connects load to the supply or disconnects load from the supply and produces a chopped load voltage from a constant input supply. Figure shows the basic principle of Choppers.



From the above figure it is clear that the SCR is triggered periodically and is kept conducting for a period Ton & is blocked for a period Toff. The chopped load voltage waveform is as shown in figure no. 2.



During the period T_{on} , when the chopper is on, the supply terminals are connected to the load terminals. & during the period T_{off} , when the chopper is 'Off", the load current flows through the Freewheeling Diode D_F . As a result, load terminals are short circuited by D_F & voltage therefore becomes zero during Toff. In this manner, a chopped DC voltage is produced at the load terminals. The average load-voltage E_o is given by

 $E_0 = E_{dc} (T_{on}/T_{on}+T_{off})$ Where

 T_{on} = 'On' time of the chopper.

Toff = 'Off' time of the chopper.

 $T(T_{on}+T_{off}) = Chopping period$

If $\alpha = T_{on}/T$ be the duty cycle then above equation becomes,

 $E_0 = E_{dc} x (T_{on}/T)$

 $E_0 = E_{dc} \times \alpha$

Thus the load voltage can be controlled by varying the duty cycle of the chopper.